

Wightman

MOBILITY QUICK REFERENCE GUIDE

YOUR DEVICE, MADE SIMPLE.
GET STARTED IN A SNAP!



WIGHTMAN MOBILITY BASICS

How to Set Up Your Voicemail

1. On your phone's dial screen, press and hold 1 to access your voicemail. If your phone has a voicemail button, you can use it instead.
2. Follow the voice prompts to set up your voice mailbox.
3. After setup is complete, press and hold 1 on your phone's keypad (or use the voicemail button) any time you want to check your messages.



Check your messages using Wightman's Voicemail to Email. This allows you to listen to voicemail messages through your email as audio files and helps to save your minutes. Call us and we can help you set it up. Best of all, it's FREE with voicemail!



Checking your voicemail uses minutes from your plan. If you check your messages outside of your local calling area, your call will also count towards your long distance minutes. Roaming charges will apply while roaming.

How to Manage Your Data Usage

How much data are you using? Since every email, video, and webpage is different, it can be hard to figure out. Here are a few tips to help you manage your data use:



- Sending and receiving photos, videos, and music uses more data than a text.
- The higher quality media, the bigger the file and the more data is used.
- Some apps use data. Some use a little, some use a lot. Track your usage when you try a new app to make sure you understand just how much data is being used.
- Automatic updates can use a lot of data without your knowledge. Check the update settings in your apps to save your data.
- Use Wi-Fi whenever possible. When you use a Wi-Fi signal to connect to the internet, you don't use any data from your plan.



Track your monthly data to avoid overage fees of 12¢/MB. Use your phone's built-in counter, apps, or Wightman's usage alert emails to stay on top of your usage. It is up to you to keep track of your data.

Canada-Wide Incoming and Outgoing Calls

Canada-Wide calling lets you call anywhere in Canada without long distance charges. When making or receiving a call on Wightman's mobile network, you use your plan's allowable Canada-Wide minutes. There are two kinds of calls on a mobile network within Canada: incoming (ILCA) and outgoing (OLCA).



Receiving Calls (ILCA)

Always the same

All calls received while in Canada (ILCA) uses your plan's allowable Canada-Wide minutes.



Making Calls (OLCA)

Changes as you move

Your outgoing calls within Canada uses your plans allowable Canada-Wide minutes. For example, if you are in Owen Sound and call St. John's, NFL, it will not be a long distance call. But if you call someone in the USA you will be subject to Wightman's International rates. For international rates, please visit wightman.ca or please call Wightman Customer Care.

Minutes used above your plan and add-ons purchased are 25¢ per minute within Canada.

Wi-Fi Setup

1. Open the Settings app.
2. Under Wireless and Network, choose Wi-Fi.
3. Drag the switch from OFF to ON to turn Wi-Fi on.
4. Your device will automatically search for available Wi-Fi signals. Once your device has found all the available networks, it will ask you to choose which one you want to connect to.
5. If a password is required to log onto the Wi-Fi network, enter it and your device will connect.



Your Android device will remember a network once it has connected to it, and will connect automatically to that network whenever it is available.

WIGHTMAN MOBILITY TIPS & TRICKS

Battery Life

Extend the life of your battery by configuring the following system settings:

1. Turn off data, Wi-Fi, Bluetooth, and GPS when not in use.
2. Reduce the number of apps running.
3. Turn off data roaming.

 *Turning data roaming off not only increases battery life, but it can also save you money! By leaving data roaming off, you'll only roam when you want to.*

Troubleshooting

Connection Issues

Wi-Fi:

Turn your Wi-Fi off and on again

If this does not resolve the issue, restart your phone

Calls:

Restart your phone

Performance Issues

Your phone's performance depends on a lot of things. How many apps you're running, how full your phone's memory is, your network or Wi-Fi connection, and the speed of your phone's processor all contribute to how fast your phone works and how long the battery lasts.

 *If your phone's performance slows suddenly, try closing or uninstalling recent apps, or try turning off your Wi-Fi. If all else fails, restart your phone. Sometimes that's all it takes.*

Finding My Phone

Can't remember where you set your phone down? Or maybe you think it's been stolen. Thanks to the Android Device Manager, you can easily find, lock, or erase your phone from any device with internet access.

To set up Android Device Manager on your phone, simply turn on your GPS service and visit www.google.com/android/devicemanager. Follow the directions there to set up remote locking and wiping of your device.

Hardware Return Policy

You can return your device to Wightman and receive a full refund if the device:

- is returned within 15 days from the date of purchase,
- has not exceeded half of the monthly usage limits, and,
- is in "like new" condition.

For more details, see your Wightman service agreement.

Security

Wightman Mobility, Samsung, and LG are not responsible for damage, loss, or breach of privacy caused by unauthorized access to your device or by malicious or illegal software. Wightman recommends that you use security on your phone to protect your personal information.

Samsung and Android both include several security measures that are easy to set up and use. They range from locking your phone with a password, to locking your SIM, to encrypting your entire device. Choose the security that's best for you, remembering that your phone may contain as much personal information as your wallet.

SAMSUNG SMART SWITCH


Smart Switch Wirelessly

Smart Switch transfers data from your old device to your new device. This feature may not be supported on some devices or computers.

Before using Smart Switch, ensure both your new and old devices are using the same Wi-Fi network and Bluetooth is turned on for both devices. When asked to use data or Wi-Fi, select Wireless option to use Wi-Fi and conserve data.

How to use Smart Switch

- 1a. On the old device, launch Smart Switch. If you do not have the app, download it from Galaxy Store or Play Store. Open the app once downloaded OR
- 1b. On your new device, go to Settings, then tap Accounts and backup. Select Smart Switch from the list and download.
2. Place the devices near each other.
3. Follow the on-screen prompts to transfer data from your old to your new device.



Visit www.samsung.com/smartswitch for more details. Samsung takes copyright seriously. Only transfer content that you own or have the right to transfer.

ANDROID BASICS

Contacts

Moving Your Contacts

A) If your previous phone was an Android device and you have backed up your contacts to your Google Account, your contacts will move with you when you sign in on your new device.

B) If your previous phone was not an Android device, here is how to move your contacts to your new phone.

On your old phone, back up your contacts to your SD card

On your new Android device

- Insert your SD card
- Open the Contacts app
- Tap the menu key
- Choose Import/Export
- Choose Import from USB storage
- Choose the contacts you want to import
- Choose the location you want them imported to

Adding New Contacts

- Open the Contacts app
- Tap the  icon
- Choose the location you want to save the contact
- Enter the contact's information
- Tap Save

Contacts Continued

Backing Up Your Contacts

- Open the Settings app
- Tap the Accounts tab and choose Google Account
- Tap on your Google Account
- Select "Contacts" from the list if it is not selected already
- Tap the settings icon in the top right and then tap Sync now
- Your contacts will sync. You can view and work with your contacts at google.ca/contacts



If you move to a new Android phone, your contacts will follow you automatically when you sign into your Google Account from your new device.



Your Google Account can back up much more than just contacts! You can also back up items like your browser favourites and Wi-Fi passwords.



Email Set-Up

Gmail Account

1. Open the Gmail app (✉)
2. **If you have** a Gmail account select Existing and enter your email address and password
3. **If you don't have** a Gmail account, select New and follow the prompts to create a new account

Wightman Account

- Open the Mail app (✉)
- Enter your Wightman email address & password
- Select either POP or iMAP
- Enter incoming mail settings
- Username is your address before the '@' sign
- Server name is 'mail.wightman.ca'
- Port must be set to '995' (POP) or '993' (IMAP)
- Enter outgoing mail settings
- Server name is 'smtp.wightman.ca'
- Port must be set to '587' using TLS
- Accept all certificates
- Select save or done to save the information
- A message will appear to advise configuring email
- Configure your email options



*Need help? Give our
24/7 Technical
Support team a call
1-888-477-2177*



MOBILITY SUPPORT



Find user guides and helpful tips for setting up and using your device at wightman.ca/support



For live technical support 24/7/365, call Wightman's local Technical Support team at 1-888-477-2177.